

Configurator HF/ HFN

| SERIE | | | | | |
|-------|-------------|------------------------------|--------------|--------------------|------------------------|
| HF | HF/ HFN | | | | |
| | Code | BODY | | | |
| | .120 | 120 | | | |
| | .220 | 220 | | | |
| | .140 | 140 | | | |
| | .240 | 240 | | | |
| | .165 | 165 | | | |
| | .265 | 265 | | | |
| | .N-114 (3) | N-114 Emergency Fluorescence | | | |
| | | Code | NORMATIVE | | |
| | | .GEN | Generation | | |
| | | | Code | LAMP TYPE | |
| | | | .118F | Fluorescence 1x18W | |
| | | | .218F | Fluorescence 2x18W | |
| | | | .136F | Fluorescence 1x36W | |
| | | | .236F | Fluorescence 2x36W | |
| | | | .158F | Fluorescence 1x58W | |
| | | | .258F | Fluorescence 1x58W | |
| | | | .112G7S | Fluorescence S11W | |
| | | | Code | LAMP | |
| | | | .SL | Without lamp | |
| | | | .CL (1) (2) | With lamp | |
| | | | | Code | CONTROL GEAR |
| | | | | .AE | Swichstart |
| | | | | .EM (3) | No permanent emergency |
| | | | | .EMP (3) | Permanent emergency |
| HF | .120 | .GEN | .118F | .SL | .AE |

(1) .CL version with lamp only available for the emergency version (.N-114).

(2) Not supplied with tubes.

(3) The armature version .N-114 can only go with the .EM and .EMP equipment.
The other versions of armor can only go with equipment .AE